




1. Interval Timer set indicator
2. Interval Timer function indicator
3. Exposure Delay set indicator
4. Exposure Delay function indicator
5. Long Time Exposure set indicator
6. Long Time Exposure function indicator
7. Daily Alarm set indicator
8. Daily Alarm function indicator
9. Freeze Focus set indicator
10. Freeze Focus function indicator
11. Film Alarm set indicator
12. Film Alarm function indicator



28. Start Time indicator (for Interval Timer)
29. Decimal point
30. Indicator for imprint between frames
31. Month indicator
32. Time indicator colon

*Not all displays appear at the same time.

13. Film Stop set indicator
14. Film Stop function indicator
15. Shutter speed indicator
16. Exposure compensation display (for Auto Bracketing)
17. Aperture indicator
18. Center value, no. of steps, no. of frames, compensation value indicator (for Auto Bracketing)
19. Frame count indicator
20. Alarm set indicator
21. Data imprint set indicator
22. Imprint level auto adjust indicator
23. Film level adjust indicator
24. Imprint level indicators
25. Second indicator
26. Data imprinted in frame
27. Year indicator
33. Fixed number indicator
34. Imprinted data between frames
35. Delay timer indicator
36. Time indicator for Interval Timer
37. Sequence number indicator
38. In-frame imprint indicator